




# COOKTOP PARTS

For Models: GS773LXSQ0, GS773LXSB0, GS773LXSS0  
(Designer White) (Black) (Stainless Steel)

30" GAS FREESTANDING  
SELF CLEAN RANGE  
SEALED BURNER  
GOLD LINE



Illus. No.	Part No.	DESCRIPTION
1	9762998	Literature Parts Installation Instructions Anti-Tip Template
	9757142	English/Spanish
	9757143	English/French
	9763003	Owners Manual
	9762984	Tech Sheet
	9762761	Safer Cooking Tips
	W10106820	Insert-Cktp Lckout


Illus. No.	Part No.	DESCRIPTION
2		Cap, Burner (LF,RF)
	3192488	Black
	9763243	White
	3192487	Black
	9763244	White
	3192486	Black
	9763242	White
4		Burner (LF)
	4455981	(LF)
	4455980	(LR,RR)
	4455979	(RR)
5		Cooktop
	8272253	Black
	8272251	White

Illus. No.	Part No.	DESCRIPTION
6		Panel, Manifold
	8523855	Black
	8523854	White
7		Knob, Control (2)
	8273279	Black
	8522623	White
8		Knob, Accusimmer
	8273280	Black
	8522624	White
9		Knob, Powerburner
	8273281	Black
	8522625	White
11		Grate, Burner (2)
	9763283	Black
	9762228	Gray
14	3400701	Screw
15	3196557	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DRAWER & BROILER PARTS

For Models: GS773LXSQ0, GS773LXSB0, GS773LXSS0  
(Designer White) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	3195996	Grill, Broiler
3	3196076	Pan, Broiler
4	8272610	Drawer, Warming
5	8274150	Enclosure, Drawer
6		Rivet, Push
	3196813	Black
	3196814	White
7		Panel, Drawer Frnt
	W10010920	Black
	W10010900	White
8	8272608	Panel, Inner
9	3196427	Screw
10	3196168	Screw

Illus. No.	Part No.	DESCRIPTION
11		Rail Assy, Drawer
	9761930	Right Side
	9761929	Left Side
12	9763728	Thermistor
13	8273414	Shield, Drawer
14	8274021	Rack, Partial
15	8274022	Rack, Insert
16	3196176	Screw
17	9758520	Element, Warming
18	8054062	Cover, Access
19	8274152	Baffle, Radiant
20	3196170	Screw

Illus. No.	Part No.	DESCRIPTION
21	9757482	Cover, Element
22	3196174	Screw
23	8524233	Insulation
24	W10010830	Bracket, Handle
25		Handle
	9761978	White
	9761979	Black
	9761981	Stainless Steel
26	W10022210	Trim - Bottom Drwr
27	W10010860	Panel, Drawer
28	W10031790	Screw
29	9781235	Speed Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

**For Models: GS773LXSQ0, GS773LXSB0, GS773LXSS0**  
**(Designer White) (Black) (Stainless Steel)**



# MANIFOLD PARTS

For Models: GS773LXSQ0, GS773LXSB0, GS773LXSS0  
(Designer White) (Black) (Stainless Steel)


Illus. No.	Part No.	DESCRIPTION
1	8273096	Screw, Valve
2		Burner Base
	8273700	Large (3)
	8273701	Small (1)
3		Tubing, Burner W/Orifice
	8273692	Left Front
	8273694	Left Rear
	9760178	Right Front
	8273697	Right Rear
4	8272470	Tubing (Manifold to Regulator)
5	8523406	Harness, Igniter (W/Switches)
6	8523793	Electrode (4)
7	8523407	Pipe, Manifold
8		Valve
	9757218	LF – RF – LR
	8273004	Right Rear
9	8273060	Nut (4)
10	8273062	Screw (4)
11	3400228	Bolt
12	8054078	Burner, Broiler
13	8053970	Spreader, Flame (Oven)
14	9758078	Burner, Bake
15	9761959	Valve/Regulator
16		Igniter
	8054129	Broil
	9758079	Bake
17	8272222	Tubing (Broiler Fitting To Valve)
18	3186489	Fitting, Broiler
19	8272403	Cover, Igniter
20		Orifice, Burner
	8273065	Left Front
	8273065	Left Rear
	8273063	Right Front
	8273067	Right Rear
21	8053262	Spreader, Flame (Broiler)
22	9758382	Valve–Soln/Shutoff
23	3196265	Screw
24	3196176	Screw
25	3196385	Screw
26	3400016	Screw
27	8523433	Tube(GPR–Shutoff)
28	W10033260	Screw
29	W10078470	Washer
30	8272893	Screw

## Following Parts Not Illustrated

8523420 Spuds, LP Gas  
(Kit of 4)

# CHASSIS PARTS

For Models: GS773LXSQ0, GS773LXSB0, GS773LXSS0  
(Designer White) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: GS773LXSQ0, GS773LXSB0, GS773LXSS0  
(Designer White) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	W10012240	Flue Box
2	8272747	Shield, Flue
3	8273036	Burner Box
4		Panel, Side (2)
	8053832	Black-Textured
	8053830	White-Textured
6	8523249	Brkt, Manifold Mtg
8		Frame, Front (Not Serviced)
9	3196037	Foot, Front (2)
10	9761935	Foot, Rear (2)
11	3195097	Bottom, Oven
12	8273902	Sensor, Oven
13	8053967	Baffle, Burner
14	9756911	Suppressor
15	9757239	Rod – Dr Switch
16	9760314	Rail, Base (2)
17	3196560	Screw (2)
18	W10008830	Seal, Oven Flange
19	9758701	Spacer, Door
20	9757098	Back, Main
21	8522416	Seal, Oven
22	8053971	Brace, Main Back
23		Retainer, Insul.
	9761449	Left Hand
	9761448	Right Hand
24	3196576	Clip, Panel (6)
25	9757891	Cord, Power
26	4449743	Screw
27	9757262	Switch, Door
28	3196701	Light Socket Assy
29	311255	Bulb, Oven Light
30	9761013	Latch, Door
31	3196960	Rod, Latch
32	9757241	Latch, Rear Asm
33	3196169	Screw
34	9760407	Brkt-Mounting
35	W10031780	Screw
36	9761490	Insulation
37	3196178	Screw
38	3196152	Screw
39	3196168	Screw
40	3196176	Screw
41	9761512	Clip-Mounting
42	3196179	Screw
43	3196178	Screw
44	3196177	Screw
45	3196168	Screw
47	3196160	Screw


## INSULATION

8524099 Insulation, Wrap  
8272614 Insulation, Back  
8272613 Insulation, Vent

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: GS773LXSQ0, GS773LXSB0, GS773LXSS0  
(Designer White) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: GS773LXSQ0, GS773LXSB0, GS773LXSS0  
(Designer White) (Black) (Stainless Steel)


Illus. No.	Part No.	DESCRIPTION
1		Endcap, Left Hand
	W10009080	Black
	W10009040	white
		Endcap, Right Hand
	W10009090	Black
	W10009050	White
2	8053505	Heat Shield, Lower
3		Panel, Control
	9762586	Black
	9762585	White
	9762588	Stainless Steel
4	9760080	Cntr Cable, Flex
5	9758080	Module, Spark
6	9757490	Support, Glass
7	8523412	Bracket, Support
8	W10036170	Cover, Upper
9	8053910	Shield, Heat
10	9760190	Cover, Lower
11	9757613	Badge Assembly
12	9763679	Control, Range
13	3196166	Screw
14	3196170	Screw
15		Glass Switch Membrn
	9763257	White
	9763264	Black
16	9762253	Bracket, DSI
17	9762221	Control
18	3196068	Lens, Light
19	8523265	Light, Indicator
20	9762589	Module, Lighting
21	3400882	Screw (2)
22		Knob-Warming Drwr
	9762581	White
	9762583	Black
23	9762855	Brkt, Mntg-Console

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# DOOR PARTS

For Models: GS773LXSQ0, GS773LXSB0, GS773LXSS0  
(Designer White) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	9762391	Trim, Top
	9761975	Black
	9761977	White
	9761977	Stainless Steel
2	3196164	Screw
3		Handle, Door
	9761979	Black
	9761978	White
	9761981	Stainless Steel
4	9761344	Liner, Door
5	9758162	Glass, Inner (2)
6	3186289	Frame, Glass
7	W10031790	Screw
8	8272618	Insulation, Door

Illus. No.	Part No.	DESCRIPTION
9	9761357	Retainer, Insul.
10	9761496	Hinge, Door
11		Glass, Outer Door
	W10010680	Black
	W10010660	White
	W10010690	Stainless Steel
12		Trim, Door Side
	8523171	Black L.H.
	8523165	Black R.H.
	8523172	White L.H.
	8523166	White R.H.
	9762249	Unvrsl Slvr L.H.
	9762250	Unvrsl Slvr R.H.

Illus. No.	Part No.	DESCRIPTION
13	3196160	Screw
14		Trim, Lower Door
	8523177	Black
	8523175	White
15	9761517	Clip, Door Mntg(2)
16	3196161	Screw
17	W10031780	Screw
19	3196025	Clip, Glass (6)
21	3196794	Bracket, Window(2)
22	3196165	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Models: GS773LXSQ0, GS773LXSB0, GS773LXSS0  
(Designer White) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

## SPLICING WIRES--25FT.

### LENGTH

242828	Wire, Black	12 Ga. 150° c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c
242827	Wire, Yellow	14 Ga. 150°c

## REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

## PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit
72032	Black
511873	White Porcelain (2 Oz.)

## PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
786020	Black
285006	Superior Black
206922	Primer (White)

## PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit (Uncut)
786032	Black (Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
--------	---------------------------------

## ANTI-TIP KIT

W10017440	Anti-Tip Kit
-----------	--------------

## WIRING HARNESS PARTS

W10095220	Harness, Main
8524207	Harness,Bake/Broil
8523599	Harness,Electrode (Cooktop-Spark)
9758531	Harness, Warming Drawer
W10045060	Harness,Grnd DSI
3196896	Clamp, Cable
3196696	Clamp, Cable
313438	Clip, Harness
3196173	Screw, Ground
3196520	Clip, Wire
3195927	Tie, Wire